

Warning

1. Do not install this unit yourself unless you are a qualified electrician
2. Do not use your hands or other matter to block up the spout, or inset wire in the spout
3. DO not disassemble , repair or make any alteration of this machine without authorization or you will risk an electric shock,fire and or other accidents

Maintenance


1. Please cut off the power and clean the shell with natural detergent when it is dirty.Do not use acid and alkalescent bathroom detergent and BEN, lacquer thinner,abrasive etc.Do not use brush or similar to avoid scratching
2. When cleaning the shell do not allow water to enter into the machine , to avoid electric shock or short circuit.
3. It's better to cut off the power when not in use , to extend the service life;
4. If the power cord is damaged , isolate the machine and consult a qualified electrician
5. If the machine breaks down,cut off the power supply and contact a qualified electrician to repair it.
6. If this machine is no longer in use, please cut off the power, and store it in a dry place indoors and seal after cleaning.

Terms of guarantee

1. The product warranty period is one year.
2. The warranty period for product will come into effect from the date of purchase.
3. If within one year after purchasing,the machine fails to function due to a manufacturing fault. Please return it to the place of purchase, for repair or replacement with a copy of the original invoice or quality assurance card stamped by the dealer.
4. The following are not in the scope of free repair or replacement :
 - ◆Improper use and the fault caused by disassembly, alteration and repair by Technical persons without our company authorization.
 - ◆Fires, earthquakes,thunder and other natural disasters cause faults, and abnormal voltage.
 - ◆The faults caused by incorrect voltage or power.
 - ◆The faults caused by operation in unsuitable conditions.
5. The warranty period has ended or the dryer has not been is not correctly maintained

Automatic high speed hand dryer

Operation instructions



Contents

Features & Technical Parameters.....	
Note before installation	1
Method of Installation	2
Method of usage.....	2
Warning	3
Maintenance	3
Terms of guarantee	3

Dear customer:

Thanks for your purchase of my company's products. Please read this instruction before installation and keep it for installation and usage or any other further reference.

Features & Technical parameters

1. It is equipped with automatic infrared ray induction system, very easy to use, reducing waste, and no touch operation which helps avoid pathogen cross infection and contamination.
2. It has outstanding performance with the latest chip control technology and infrared sensor.
3. It has unified high speed motor with RPM of 25000, dries the hands within 7- 12 seconds;
4. This series product has all over current protection, which effectively eliminates accidents.
5. It only needs wall plugs and screws to hang the machine, ensure you cut off the power before installation. It is suitable for all departments in hospitals, schools, food and pharmaceutical manufacturers, airports, office buildings, hotels, government agencies and research institutions and other places.

Rated Voltage	AC220 - 240V	Waterproof Grade	IPX1
Rated Frequency	50/60HZ	Wind Speed	90m/s
Rated Power	1800W	Sensing Distance	12±3cm
Motor power	600W	Drying Time	7- 12S
Ambient Temperature	0-40°C	Installation	Wall Mounting
Way Of Heating	heating wire	Overall size	320 × 290 × 170

Note: before installation


Warning

1. Do not fix it in the place with water or water vapor in surface, do not install in the bathroom which with heavy moisture, in order to avoid electric shock.
2. You must commission professional electrician to install this hand dryer.
3. The machine must be installed in clean dry area. Please use power: 220V -240V, 50/60Hz dependent on the country of use

Attention


1. Ensure that there are no obstructions below the outlet around 400mm. Also, do not install it above the stainless steel or artificial marble such shining surface location, otherwise prone to misoperation.
2. The body should be firmly fixed to the smooth wall to avoid injuries caused by the machine falling or product damage.
3. Do not install the products in such place with corrosive or flammable gases or objects, it may cause fire or product failure and malfunction.
4. Do not install the products in such environment with lots of dust or in high temperature, it may cause product damage.

Method of Installation



Installation method

1. Use the hexagon wrench in the attachment to remove the screws on the two sides, and take off the shell. (PICTURE 1)
2. Drill hole on the wall according to dimensional drawing, and put the plastic wall plug in the hole. We suggest that you take off the machine shell when you have marked the position and then drill the hole.
3. Use the four screws to fix the product on the wall. (PICTURE 2)
4. Cover the shell, and fix the cover using the screws provided with hexagon wrench, plug in and power up to check it is working (PICTURE 3)



Method of usage

When the installation is finished, turn on the power, the machine will be in standby mode. Put your hands under the outlet with a distance of 10cm, the machine will start automatically. Warm air will come out drying the hands. When you take away your hands, the machine will stop working automatically within 2 seconds. After the machine has worked for 60 seconds continually, it will stop working automatically. If you want the machine to start again, you need to place your hands under the sensor.